

Panasonic®

Operating Instructions

Digital Cordless Phone

Model No. **KX-TG2711FX**
KX-TG2712FX



Model shown is KX-TG2711.

***Before initial use, see “Getting Started”
on page 9.***

Thank you for purchasing a Panasonic product.

Please read these operating instructions before using the unit and save them for future reference.

To use this unit in your country, first change the unit's region setting to match your country (page 20). Change the unit's display language as needed (page 12).

(For Czech and Slovakia)

This cordless telephone is possible to use according to General licence No.: VO-R/8/08.2005-23 (for Czech), VPR-7/2001 (for Slovakia).

Getting Started

Note when setting up

Note for connections

- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)
- The AC adaptor should be connected to a vertically oriented or floor-mounted AC outlet. Do not connect the AC adaptor to a ceiling-mounted AC outlet, as the weight of the adaptor may cause it to become disconnected.

During a power failure

The unit will not work during a power failure. We recommend connecting a corded-type telephone (without AC adaptor) to the same telephone line or to the same telephone line jack, if you have such a telephone jack in your house.


Note for battery installation




- Use the supplied rechargeable batteries. For replacement, we recommend using the Panasonic rechargeable batteries noted on page 4, 6.
- Wipe the battery ends (⊕, ⊖) with a dry cloth.
- Avoid touching the battery ends (⊕, ⊖) or the unit contacts.

Note for battery charging

- It is normal for the handset to feel warm during charging.
- Clean the charge contacts of the handset, base unit, and charger with a soft and dry cloth once a month. Before cleaning the unit, disconnect from power outlets and any telephone line cords. Clean more often if the unit is exposed to grease, dust, or high humidity.

Battery level

Icon	Battery level
	High

Icon	Battery level
	Medium
	Low
	Needs charging.

Panasonic Ni-MH battery performance (supplied batteries)


Operation	Operating time
In continuous use	20 hours max.
Not in use (standby)	170 hours max.

Note:

- It is normal for batteries not to reach full capacity at the initial charge. Maximum battery performance is reached after a few complete cycles of charge/discharge (use).
- Actual battery performance depends on usage and ambient environment.
- Even after the batteries are fully charged, the handset can be left on the base unit or charger without any ill effect on the batteries.
- The battery level may not be displayed correctly after you replace the batteries. In this case, place the handset on the base unit or charger and let it charge for at least 7 hours.

Controls


Handset



- 1 Speaker
- 2 [☐/C] (Phonebook/Clear)
- 3 [☎] (Speakerphone)
- 4 [☎] (Talk)
- 5 Dial keypad
- 6 Receiver
- 7 Display
- 8 [☰/OK] (Menu/OK)
- 9 [⏏/P] (Mute/Pause)

- 10 [R/ECO]
R: Recall/Flash
ECO: Eco mode shortcut key
- 11 [⏻] (Off/Power)
- 12 Microphone
- 13 Charge contacts
- A Navigator key
 - [▲], [▼], [←], or [→]: Scroll through various lists and items.
 - [🔊] (Volume: [▲] or [▼]): Adjust the receiver or speaker volume while talking.
 - [☎] (☎): Caller list: View the caller list.
 - [☎] (☎): Redial: View the redial list.

Base unit








- 1 [📶] (Locator)
- 2 Charge contacts

Display

Handset display items

Item	Meaning
📶	Range status: The more bars visible, the closer the handset is to the base unit. <ul style="list-style-type: none"> • When 📶 is flashing: Handset is searching for base unit. (page 29)

Getting Started

Item	Meaning
	Handset is accessing base unit (intercom* ¹ , paging, changing base unit settings, etc.).
	Handset is on an outside call. <ul style="list-style-type: none">• When flashing slowly: The call is put on hold.• When flashing rapidly: An incoming call is now being received.
ECO	The base unit transmission power is set to "Low". (page 13)
	Battery level
	Alarm is on. (page 20)
[P]	Privacy mode is on.* ¹ (page 19)
	New voice mail message received.* ² (page 24)
[IN USE]	Someone is using the line.* ¹

*1 KX-TG2712

*2 Voice mail subscribers only

Turning the power on/off

Power on


Press [] for about 1 second.



Power off

Press [] for about 2 seconds.

Initial settings

Symbol meaning:

Example: []: "Off"

Press [] or [] to select the words in quotations.

Region settings

You can set the unit to use settings that match your country (page 20). The display language and other settings will change accordingly.

Note:

- The display language only changes (to the selected country's default setting) for the handset used to select the region setting. You must change the display language for all other handsets separately.











Display language

Important:










- When the language selection is displayed after installing the batteries for the first time, perform step 5.

16 display languages are available.

You can select "Deutsch", "English", "Magyar", "POLSKI", "Slovenčina", "Čeština", "Hrvatski", "Slovenscina", "Eesti", "Lietuviškai", "Latviešu", "ROMÂNĂ", "БЪЛГАРСКИ", "Srpski", "МАКЕДОНСКИ", or "Shqip".

- 1 [/OK]
- 2 []: "Handset Setup" → [/OK]
- 3 []: "Display Setup" → [/OK]
- 4 []: "Select Language" → [/OK]
- 5 []: Select your desired language. → [/OK] → []

Note:

- If you select a language you cannot read:
[] → [/OK] → [] 3 times → [/OK] → [] 3 times → [/OK] 2 times → []: Select your desired language. → [/OK] → []

Date and time

- 1 [/OK]

- 2 [↕]: "Handset Setup" → [OK]
- 3 [↕]: "Set Date & Time" → [OK]
- 4 Enter the current date, month, and year.
Example: 15 July, 2012
[1][5][0][7][1][2]
- 5 Enter the current hour and minute.
Example: 9:30
[0][9][3][0]
 - You can select 24-hour or 12-hour clock format ("AM" or "PM") by pressing [X].
- 6 [OK] → [Power Off]

Note:

- The date and time may be incorrect after a power failure. In this case, set the date and time again.

Dialling mode

If you cannot make calls, change this setting according to your telephone line service. The default setting is "Tone".

"Tone": For tone dial service.

"Pulse": For rotary/pulse dial service.

- 1 [OK]
- 2 [↕]: "Base Unit Setup" → [OK]
- 3 [↕]: "Dial Mode" → [OK]
- 4 [↕]: Select the desired setting. → [OK] → [Power Off]

One touch eco mode

When the handset is on the base unit, the base unit transmission power is reduced up to 99.9 % if only one handset is registered.

Even when the handset is not on the base unit or several handsets are registered, the base unit transmission power in standby mode can be reduced up to 90 % by activating one touch eco mode.

You can turn on/off one touch eco mode by just pressing [R/ECO]. The default setting is "Normal".

- When the one touch eco mode is on: "Low" is temporarily displayed and "ECO" is shown on the handset display.
- When the one touch eco mode is off: "Normal" is temporarily displayed and "ECO" goes off from the handset display.

Note:

- When there is another cordless phone nearby and it is in use, the base unit transmission power may not be reduced. (KX-TG2712)
- Activating one touch eco mode reduces the range of the base unit in standby mode.
- If you set the repeater mode to "On" (page 21), one touch eco mode is cancelled.

Making/Answering Calls

Making calls

- 1 Lift the handset and dial the phone number.
 - To correct a digit, press [□□/C].
- 2 [↶]
- 3 When you finish talking, press [📞] or place the handset on the base unit or charger.

Using the speakerphone

- 1 Dial the phone number and press [📞].
 - Speak alternately with the other party.
- 2 When you finish talking, press [📞].

Note:

- For best performance, use the speakerphone in a quiet environment.
- To switch back to the receiver, press [📞]/ [↶].

Adjusting the receiver or speaker volume

Press [▲] or [▼] repeatedly while talking.

Making a call using the redial list

The last 10 phone numbers dialled are stored in the redial list (each 24 digits max.).

- 1 [▶] (●)
- 2 [↕]: Select the desired phone number.
- 3 [↶]

Erasing a number in the redial list

- 1 [▶] (●)
- 2 [↕]: Select the desired phone number.
→ [☑/OK] 2 times
- 3 [↕]: "Yes" → [☑/OK] → [📞]

Pause (for PBX/long distance service users)

A pause is sometimes required when making calls using a PBX or long distance service.

When storing a calling card access number and/or PIN in the phonebook, a pause is also needed (page 16).

Example: If you need to dial the line access number "0" when making outside calls with a PBX:

- 1 [0] → [☑/P]
- 2 Dial the phone number. → [↶]

Note:

- A 3 second pause is inserted each time [☑/P] is pressed.

Answering calls

- 1 Lift the handset and press [↶] or [📞] when the unit rings.
 - You can also answer the call by pressing any dial key from [0] to [9], [✖], or [#]. (**Any key answer feature**)
- 2 When you finish talking, press [📞] or place the handset on the base unit or charger.

Auto talk

You can answer calls simply by lifting the handset off the base unit or charger. You do not need to press [↶]. To turn this feature on, see page 18.

Adjusting the handset ringer volume

- **While the handset is ringing for an incoming call:**
Lift the handset and press [▲] or [▼] repeatedly to select the desired volume.
- **Programming the volume beforehand:**
 - 1 [☑/OK]
 - 2 [↕]: "Handset Setup" → [☑/OK]
 - 3 [↕]: "Ringer Setup" → [☑/OK]
 - 4 [↕]: "Ringer Volume" → [☑/OK]
 - 5 [↕]: Select the desired volume.
 - 6 [☑/OK] → [📞]

Temporary handset ringer off

While the handset is ringing for a call, you can turn the ringer off temporarily by pressing [🔕].

Useful features during a call

Hold

This feature allows you to put an outside call on hold.

- 1 Press [📠/OK] during an outside call.
- 2 [📞]: "Hold" → [📠/OK]
- 3 To release hold, press [📞].
 - Another handset user can take the call by pressing [📞]. (KX-TG2712)

Note:

- If a call is kept on hold for more than 9 minutes, the call rings at your handset again. After 1 additional minute on hold, the call is disconnected.
- If another phone is connected to the same line, you can also take the call by lifting its handset.

Mute

While mute is turned on, you can hear the other party, but the other party cannot hear you.

- 1 Press [🔇/P] during conversation.
- 2 To return to the conversation, press [🔇/P] again.

Recall/flash

[R/ECO] allows you to use the special features of your host PBX such as transferring an extension call, or accessing optional telephone services.

Note:

- To change the recall/flash time, see page 19.

For call waiting or Call Waiting Caller ID service users

To use call waiting or Call Waiting Caller ID, you must first subscribe with your service provider/telephone company.

This feature allows you to receive calls while you are already talking on the phone. If you receive a call while on the phone, you will hear a call waiting tone.

If you subscribe to both Caller ID and Call Waiting with Caller ID services, the 2nd caller's information is displayed after you hear the call waiting tone on the handset.

- 1 Press [R/ECO] to answer the 2nd call.
- 2 To switch between calls, press [R/ECO].

Note:

- Please contact your service provider/telephone company for details and availability of this service in your area.

Temporary tone dialling (for rotary/pulse service users)

You can temporarily switch the dialling mode to tone when you need to access touch-tone services (for example, answering services, telephone banking services, etc.). Press [📞] before entering access numbers which require tone dialling.

Call share

Available for:
KX-TG2712

You can join an existing outside call. To join the conversation, press [📞] when the other handset is on an outside call.

Note:

- To prevent other users from joining your conversations with outside callers, turn the privacy mode on (page 19).

Phonebook

Handset phonebook

The phonebook allows you to make calls without having to dial manually. You can add 50 names and phone numbers.

Adding entries

- 1 [□/C] → [≡/OK]
- 2 [↕]: “New Entry” → [≡/OK]
- 3 Enter the party’s name (16 characters max.). → [≡/OK]
 - You can change the character entry mode by pressing [✕/P] (page 26).
- 4 Enter the party’s phone number (24 digits max.). → [≡/OK]
- 5 [↕]: “Save” → [≡/OK]
 - To add other entries, repeat from step 3.
- 6 [↻/⏻]

Finding and calling from a phonebook entry

Scrolling through all entries

- 1 [□/C]
- 2 [↕]: Select the desired entry.
 - You can scroll through the phonebook entry by pressing and holding [▼] or [▲].
- 3 [↻]

Searching by first character

- 1 [□/C]
 - Change the character entry mode if necessary:
[✕/P] → [↕]: Select the character entry mode. → [≡/OK]
- 2 Press the dial key ([0] to [9]) which contains the character you are searching for (page 26).
 - Press the same dial key repeatedly to display the first entry corresponding to each character located on that dial key.

- If there is no entry corresponding to the character you selected, the next entry is displayed.

- 3 [↕]: Scroll through the phonebook if necessary.
- 4 [↻]

Editing entries

- 1 Find the desired entry (page 16). → [≡/OK]
- 2 [↕]: “Edit” → [≡/OK]
- 3 Edit the name if necessary (16 characters max.; page 26). → [≡/OK]
- 4 Edit the phone number if necessary (24 digits max.). → [≡/OK]
- 5 [↕]: “Save” → [≡/OK]
- 6 [↻/⏻]

Erasing entries

- 1 Find the desired entry (page 16). → [≡/OK]
- 2 [↕]: “Erase” → [≡/OK]
- 3 [↕]: “Yes” → [≡/OK] → [↻/⏻]

Copying phonebook entries

Available for:
KX-TG2712

You can copy phonebook entries between 2 handsets.

Copying an entry

- 1 Find the desired entry (page 16). → [≡/OK]
- 2 [↕]: “Copy” → [≡/OK]

- 3** Enter the handset number you wish to send the phonebook entry to.
- When an entry has been copied, “Completed” is displayed.
 - To continue copying another entry:
[↕]: “Yes” → [☒/OK] → [↕]:
Select the desired entry. → [☒/OK]

4 [✖️🔌]

Copying all entries

- 1** [☐/C] → [☒/OK]
- 2** [↕]: “Copy All” → [☒/OK]
- 3** Enter the handset number you wish to send the phonebook entry to.
- When all entries have been copied, “Completed” is displayed.
- 4** [✖️🔌]

Programming

Programmable settings

You can customise the unit by programming the following features using the handset.

Scrolling through the display menus


- 1 [OK]
- 2 Press [▼] or [▲] to select the desired main menu. → [OK]
- 3 Press [▼] or [▲] to select the desired item in sub-menu 1. → [OK]
 - In some cases, you may need to select from sub-menu 2. → [OK]
- 4 Press [▼] or [▲] to select the desired setting. → [OK]
 - This step may vary depending on the feature being programmed.
 - To exit the operation, press [Power Off].

Note:

- In the following table, < > indicates the default settings.
- In the following table, (P) indicates the reference page number.
- Display menu order and sub-menu may vary depending on your model.

Main menu	Sub-menu 1	Sub-menu 2	(P)	
Caller List	-	-	22	
Intercom*1	-	-	25	
Ph.Book Setup	New Entry	-	16	
	Copy All*1	-	17	
Handset Setup	Set Date & Time*2	-	12	
	Alarm <Off>	-	20	
	Ringer Setup	Ringer Volume <Level 6>		14
		Ringtone*3, *4 <Ringtone 1>		-
	Display Setup	Select Language*5 <English>		12
		Contrast <Level 3>		-
	Register H.set	-		31
	Keytones*6 <On>	-		-
Auto Talk*7 <Off>	-		14	

Programming

Main menu	Sub-menu 1	Sub-menu 2	
Base Unit Setup ^{*2}	First Ring ^{*8} <On>	–	–
	Dial Mode <Tone>	–	13
	Recall/Flash ^{*9, *10} <600 msec.>	–	15
	Privacy Mode ^{*1, *11} <Off>	–	–
	Base Unit PIN	–	31
	Repeater Mode <Off>	–	21
	Country <Other>	–	20

*1 KX-TG2712

*2 If you program these settings using one of the handsets, you do not need to program the same item using another handset. (KX-TG2712)

*3 The ringer tone may continue to play for several seconds even if the caller has already hung up. You may either hear a dial tone or no one on the line when you answer the call.

*4 The preset melodies in this product are used with permission of © 2011 Copyrights Vision Inc.

*5 The default display language will be as follows if you select the following regional codes when changing the unit's region setting (page 12):

“Other” = “English”

“Česká republika” = “Čeština”

“Slovensko” = “Slovenčina”

*6 Turn this feature off if you prefer not to hear key tones while you are dialling or pressing any keys, including confirmation tones and error tones.

*7 If you subscribe to a Caller ID service and want to view the caller's information after lifting up the handset to answer a call, turn off this feature.

*8 If you do not want the unit to ring before the caller information is received, set to “OFF”.
(Caller ID subscribers only)

You can only remove the first ring if the unit rings two times or more by default, which depends on your service provider/telephone company.

*9 The recall/flash time depends on your telephone exchange or host PBX. Contact your PBX supplier if necessary.

*10 The default setting will be as follows if you select the following regional codes when changing the unit's region setting (page 20):

“Česká republika” = “100 msec.”

“Slovensko” = “100 msec.”

*11 To prevent other users from joining your conversations with outside callers, turn this feature on.

Programming

Special programming

Alarm

An alarm sounds at the set time for 3 minutes once or daily. Alarm can be set for each handset.

Important:

- Set the date and time beforehand (page 12).

- 1 [/OK]
- 2 []: "Handset Setup" → [/OK]
- 3 []: "Alarm" → [/OK]
- 4 []: Select the desired alarm option. → [/OK]

"Off" Turns alarm off. Go to step 8.
"Once" An alarm sounds once at the set time.
"Daily" An alarm sounds daily at the set time. Go to step 6.

- 5 Enter the desired date and month.
- 6 Set the desired time. → [/OK]
- 7 []: Select the desired alarm tone. → [/OK]
 - We recommend selecting a different ringer tone from the one used for outside calls.
- 8 [/OK] → []
 - When the alarm is set, is displayed.

Note:

- To stop the alarm, lift the handset and press [] or place the handset on the base unit or charger.
- When the handset is in use, the alarm will not sound until the handset is in standby mode.

Changing the unit's region setting/Resetting the base unit

- 1 [/OK]
- 2 []: "Base Unit Setup" → [/OK]
- 3 []: "Country" → [/OK]
- 4 []: Select the desired country. → [/OK]
"Other" = countries except Czech and Slovakia
"Česká republika" = Czech
"Slovensko" = Slovakia
- 5 []: "Yes" → [/OK] → []

Note:

- The following items will be deleted or reset to their default settings:
 - Base unit settings (page 19)
 - One touch eco mode (page 13)
 - Caller list
 - Voice mail messages
- The following items will be retained:
 - Date and time
 - Repeater mode
- If you select the desired country in step 4, the following default settings will be changed for the selected country's default settings:
 - Recall/flash time (page 19)
 - Display language (page 18)
- After changing the unit's region setting/ resetting the base unit, may flash on the handset momentarily. This is normal and the handset can be used once stops flashing.

Increasing the range of the base unit









You can increase the signal range of the base unit by using a DECT repeater. Please use only the Panasonic DECT repeater noted on page 4. Contact your Panasonic dealer for details.

Important:



- Before registering the repeater to this base unit, you must turn the repeater mode on.

- Do not use more than one repeater at a time.

Setting the repeater mode

- 1 **[/OK]**
- 2 **[]:** “Base Unit Setup” → **[/OK]**
- 3 **[]:** “Repeater Mode” → **[/OK]**
- 4 **[]:** Select the desired setting. → **[/OK]** → **[**





Note:

- After turning the repeater mode on or off,  may flash on the handset momentarily. This is normal and the handset can be used once  stops flashing.

Registering the DECT repeater (KX-A405) to the base unit

Note:

- Please use a repeater that has not yet been registered to another unit. If the repeater is registered to another unit, deregister it first, referring to the Installation Guide for the DECT repeater.

- 1 **Base unit:**
Press and hold **[**] for about 5 seconds.
(No registration tone)
 - The next step must be completed within 90 seconds.
- 2 **DECT repeater:**
Connect the AC adaptor, then wait until the  indicator and  indicator light green.
- 3 **Base unit:**
To exit the registration mode, press **[**].

Caller ID Service

Using Caller ID service

Important:

- This unit is Caller ID compatible. To use Caller ID features, you must subscribe to Caller ID service. Contact your service provider/telephone company for details.

Caller ID features

When an outside call is being received, the caller information is displayed.

Caller information for the last 50 callers is logged in the caller list from the most recent call to the oldest.

- If the unit cannot receive caller information, the following is displayed:
 - “**Out of Area**”: The caller dials from an area which does not provide a Caller ID service.
 - “**Private Caller**”: The caller requests not to send caller information.
- If the unit is connected to a PBX system, caller information may not be properly received. Contact your PBX supplier.

Missed calls

If a call is not answered, the unit treats it as a missed call and “**Missed Call**” is displayed. This lets you know if you should view the caller list to see who called while you were away.

Even if only one missed call in the caller list is viewed (page 22), “**Missed Call**” disappears from the display. When you receive another new call, “**Missed Call**” is displayed again.

Note:

- Even when there are unviewed missed calls, “**Missed Call**” disappears from the standby display if the following operation is performed by one of the registered handsets:
 - Being replaced on the base unit or charger.
 - Pressing [**📞**].

Phonebook name display

When caller information is received and it matches a phone number stored in the phonebook, the stored name in the phonebook is displayed and logged in the caller list.

Caller list

Important:

- Only 1 person can access the caller list at a time.
- Make sure the unit’s date and time setting is correct (page 12).

Viewing the caller list and calling back

- 1 [**←**] (**→**)
- 2 Press [**▼**] to search from the most recent call, or press [**▲**] to search from the oldest call.
- 3 To call back, press [**📞**].
To exit, press [**📞**].

Note:

- If the entry has already been viewed or answered, “**✓**” is displayed, even if it was viewed or answered using another handset.

Editing a caller’s phone number before calling back

- 1 [**←**] (**→**)
- 2 [**↕**]: Select the desired entry. →
[**☑**]/**OK**
- 3 [**↕**]: “**Edit and Call**” → [**☑**]/**OK**
- 4 Edit the number.
 - Press dial key (**0** to **9**) to add, [**☐**]/**C** to delete.
- 5 [**📞**]

Erasing caller information

- 1 [**←**] (**→**)
- 2 [**↓**]: Select the desired entry. →
[**☐**/OK]
- 3 [**↓**]: "Erase" or "Erase All" →
[**☐**/OK]
- 4 [**↓**]: "Yes" → [**☐**/OK] → [**✕**⏻]


Storing caller information to the phonebook

- 1 [**←**] (**→**)
- 2 [**↓**]: Select the desired entry. →
[**☐**/OK]
- 3 [**↓**]: "Add Phonebook" → [**☐**/OK]
- 4 To store the name, continue from step 3, "Adding entries", page 16.



Voice Mail Service

Voice mail service

Voice mail is an automatic answering service offered by your service provider/telephone company. After you subscribe to this service, your service provider/telephone company's voice mail system answers calls for you when you are unavailable to answer the phone or when your line is busy. Messages are recorded by your service provider/telephone company, not your telephone.

When you have new messages,  is displayed on the handset if message indication service is available. Please contact your service provider/telephone company for details of this service.

Important:

- If  still remains on the display even after you have listened to new messages, turn it off by pressing and holding  for 2 seconds.

Intercom

Available for:
KX-TG2712

Intercom calls can be made between handsets.

Note:

- When paging the handset, the paged handset beeps for 1 minute.
- If you receive an outside call while talking on the intercom, you hear 2 tones. To answer the call, press [📞], then press [📞].

Making an intercom call

- 1 [📞/OK]
- 2 [📞]: "Intercom" → [📞/OK]
- 3 To page a specific handset, enter the handset number.
 - To stop paging, press [📞].
- 4 When you finish talking, press [📞].

Answering an intercom call

- 1 Press [📞] to answer the page.
- 2 When you finish talking, press [📞].

Handset locator

You can locate a misplaced handset by paging it.

- 1 **Base unit:** Press [📞].
 - All registered handsets beep for 1 minute.
- 2 To stop paging:
Base unit: Press [📞].
Handset: Press [📞].

Transferring calls, conference calls

Available for:
KX-TG2712

Outside calls can be transferred or a conference call with an outside party can be made between 2 handsets.

- 1 During an outside call, press [📞/OK].
- 2 [📞]: "Intercom" → [📞/OK]
 - 📞 flashes to indicate the outside call is on hold.
- 3 Enter the desired handset number you want to transfer to.
- 4 Wait for the paged party to answer.
 - If the paged party does not answer, press [📞] to return to the outside call.
- 5 **To complete the transfer:**
Press [📞].
 - The outside call is being routed to the destination unit.**To establish a conference call:**
Press [📞].
 - To leave the conference, press [📞]. The other 2 parties can continue the conversation.
 - To put the outside call on hold, press [📞/OK]. → [📞]: "Hold" → [📞/OK]
To resume the conference, press [📞].

Answering a transferred call

Press [📞] to answer the page.

Useful Information

Character entry

The dial keys are used to enter characters and numbers. Each dial key has multiple characters assigned to it. The characters that can be entered depend on the character entry mode (page 26).

- Press [◀] or [▶] to move the cursor left or right.
- Press dial keys to enter characters and numbers.
- Press [□/C] to erase the character or number highlighted by the cursor. Press and hold [□/C] to erase all characters or numbers.
- Press [A→a] to switch between uppercase and lowercase.
- To enter another character located on the same dial key, press [▶] to move the cursor to the next space, then press the appropriate dial key.

Character entry modes

The available character entry modes are Alphabet (ABC), Numeric (0-9), Greek (ΑΒΓ), Extended 1 (ΑΆΆ), Extended 2 (ΣΣΣ), and Cyrillic (АБВ). When in these entry modes except Numeric, you can select which character is entered by pressing a dial key repeatedly.

When the unit displays the character entry screen:

[☒/P] → [↕]: Select a character entry mode. → [☒/OK]

Note:

- ◻ in the following tables represents a single space.

Alphabet character table (ABC)

0	1	2	3	4	5	6	7	8	9
◻ 0	◻ # & ' () * , - . / 1	A B C 2	D E F 3	G H I 4	J K L 5	M N O 6	P Q R S 7	T U V 8	W X Y Z 9
		a b c 2	d e f 3	g h i 4	j k l 5	m n o 6	p q r s 7	t u v 8	w x y z 9

Numeric entry table (0-9)

0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9

Greek character table (ΑΒΓ)

0	1	2	3	4	5	6	7	8	9
◻ 0	◻ # & ' () * , - . / 1	A B Γ 2	Δ E Z 3	H Θ I 4	K Λ M 5	N Ξ O 6	Π Ρ Σ 7	T Υ Φ 8	X Ψ Ω 9

Useful Information

Extended 1 character table (AĂÄ)

0	1	2	3	4	5	6	7	8	9
└ 0	└ # & ' () * , - . / 1	A Á Â Ã Ä Å Ă Ą Ć Ç 2	D E Ę Ě É Ê Ë Ę Ě F 3	G Ğ Ħ I Ĩ Í Î Ĳ Ĳ 4	J K L 5	M N Ń O Ő Ó Ō Ö Ø ø 6	P Q R S Ş ß 7	T U Ú Ú Ū Ů Ů V 8	W Ŵ X Y ŷ Z 9
		a à á â ä å ă ă ă ą æ b ç ç 2	d e è é ê ë ę f 3	g ħ h i ĩ í î î ĳ ĳ 4	j k l 5	m n ñ o ò ó ô ö ø ø 6	p q r s Ş ß 7	t u ù ú û ü ŭ v 8	w ŵ x y ŷ z 9

- The following are used for both uppercase and lowercase: ø Ş Ŵ ŷ

Extended 2 character table (ŠŠŠ)

0	1	2	3	4	5	6	7	8	9
└ 0	└ # & ' () * , - . / 1	A Á Ā A B C Ā Ć 2	D Ď Ě É Ě Ě Ā Ć 3	G H I Í 4	J K L Ł Ł Ł 5	M N Ń Ń Ő Ő Ō Ő 6	P Q R Ŕ Ŕ Ŕ Ś Ś 7	T Ť U Ú Ū Ů Ů V 8	W X Y Ÿ Ź Ž Ž Ž Ž 9
		a á ā A b c Ā Ć 2	d ě ě é ě ě f 3	g h i í 4	j k l ł Ł Ł 5	m n ñ ň ó ó ō ő 6	p q r ŕ ŕ ŕ ś ś 7	t ŧ u ú ū ů ů v 8	w x y ÿ ź ž ž ž ž 9

- The following are used for both uppercase and lowercase:

Ą Ć Ć Ę Ł Ł Ł Ń Ŕ Ŕ Ś Ÿ Ź Ž Ž

Cyrillic character table (АБВ)

0	1	2	3	4	5	6	7	8	9
└ 0 Ğ € I İ ŷ	└ # & ' () * , - . / 1	A Б В Г 2	Д Е Ж З 3	И Й К Л 4	М Н О П 5	Р С Т У 6	Ф Х Ц Ч 7	Ш Щ Ъ Ы 8	Ь Э Ю Я 9

Useful Information

Error messages

Display message	Cause/solution
Failed	<ul style="list-style-type: none">● Phonebook copy failed (page 16). Confirm the other handset (the receiver) is in standby mode and try again.
Incomplete	<ul style="list-style-type: none">● The receiver's phonebook memory is full. Erase the unwanted phonebook entries from the other handset (the receiver) and try again.
Memory Full	<ul style="list-style-type: none">● The phonebook memory is full. Erase unwanted entries (page 16).
No link to base. Reconnect AC adaptor.	<ul style="list-style-type: none">● The handset has lost communication with the base unit. Move closer to the base unit and try again.● Unplug the base unit's AC adaptor to reset the unit. Reconnect the adaptor and try again.● The handset's registration may have been cancelled. Re-register the handset (page 31).

Troubleshooting

If you still have difficulties after following the instructions in this section, disconnect the base unit's AC adaptor and turn off the handset, then reconnect the base unit's AC adaptor and turn on the handset.

General use

Problem	Cause/solution
The handset does not turn on even after installing charged batteries.	<ul style="list-style-type: none">● Place the handset on the base unit or charger to turn on the handset.
The unit does not work.	<ul style="list-style-type: none">● Make sure the batteries are installed correctly (page 9).● Fully charge the batteries (page 9).● Check the connections (page 9).● Unplug the base unit's AC adaptor to reset the unit and turn off the handset. Reconnect the adaptor, turn on the handset and try again.● The handset has not been registered to the base unit. Register the handset (page 31).
The handset display is blank.	<ul style="list-style-type: none">● The handset is not turned on. Turn the power on (page 12).



Useful Information

Problem	Cause/solution
I cannot hear a dial tone.	<ul style="list-style-type: none"> • Make sure that you are using the supplied telephone line cord. Your old telephone line cord may have a different wiring configuration. • The base unit's AC adaptor or telephone line cord is not connected. Check the connections. • Disconnect the base unit from the telephone line and connect the line to a known working telephone. If the working telephone operates properly, contact our service personnel to have the unit repaired. If the working telephone does not operate properly, contact your service provider/telephone company.
I cannot use the intercom or phonebook copy feature.	<ul style="list-style-type: none"> • These features are available between the handsets. Although the handset displays "Intercom", "Copy All", or "Copy", these features are not available for single handset models.


Programmable settings

Problem	Cause/solution
The display is in a language I cannot read.	<ul style="list-style-type: none"> • Change the display language (page 12).
I cannot activate the eco mode.	<ul style="list-style-type: none"> • You cannot set eco mode when you set the repeater mode "On". If required, set the repeater mode to "Off" (page 21).

Battery recharge

Problem	Cause/solution
The handset beeps and/or  flashes.	<ul style="list-style-type: none"> • Battery charge is low. Fully charge the batteries (page 9).
I fully charged the batteries, but <ul style="list-style-type: none"> –  still flashes or – the operating time seems to be shorter. 	<ul style="list-style-type: none"> • Clean the battery ends (+, -) and the charge contacts with a dry cloth and charge again. • It is time to replace the batteries (page 9).

Making/answering calls, intercom

Problem	Cause/solution
 is flashing.	<ul style="list-style-type: none"> • The handset is too far from the base unit. Move closer. • The base unit's AC adaptor is not properly connected. Reconnect AC adaptor to the base unit. • The handset is not registered to the base unit. Register it (page 31). • Activating one touch eco mode reduces the range of the base unit in standby mode. If required, turn eco mode off (page 13).

Useful Information

Problem	Cause/solution
Noise is heard, sound cuts in and out.	<ul style="list-style-type: none">• You are using the handset or base unit in an area with high electrical interference. Re-position the base unit and use the handset away from sources of interference.• Move closer to the base unit.• If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details.
The handset does not ring.	<ul style="list-style-type: none">• The ringer volume is turned off. Adjust ringer volume (page 14).
I cannot make a call.	<ul style="list-style-type: none">• The dialling mode may be set incorrectly. Change the setting (page 13).

Caller ID

Problem	Cause/solution
Caller information is not displayed.	<ul style="list-style-type: none">• You must subscribe to a Caller ID service. Contact your service provider/telephone company for details.• If your unit is connected to any additional telephone equipment, remove and plug the unit directly into the wall jack.• If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details.• Other telephone equipment may be interfering with this unit. Disconnect the other equipment and try again.
Caller information is slow to display.	<ul style="list-style-type: none">• Depending on your service provider/telephone company, the unit may display the caller's information at the 2nd ring or later. Set the first ring to "o££" (page 19).• Move closer to the base unit.
The name stored in the phonebook is not fully displayed while an outside call is being received.	<ul style="list-style-type: none">• Edit the phonebook entry name to fit in 1 line of text (page 16).










Liquid damage

Problem	Cause/solution
Liquid or other form of moisture has entered the handset/base unit.	<ul style="list-style-type: none">• Disconnect the AC adaptor and telephone line cord from the base unit. Remove the batteries from the handset and leave to dry for at least 3 days. After the handset/base unit are completely dry, reconnect the AC adaptor and telephone line cord. Insert the batteries and charge fully before use. If the unit does not work properly, contact an authorised service centre.












Caution:

- To avoid permanent damage, do not use a microwave oven to speed up the drying process.

Registering a handset to the base unit

- 1 Handset:**
[/OK]
- 2** []: “Handset Setup” → [/OK]
- 3** []: “Register H.set” → [/OK]
- 4 Base unit:**
Press and hold [] for about 5 seconds. (No registration tone)
 - If all registered handsets start ringing, press [] again to stop, then repeat this step. (KX-TG2712)
 - The next step must be completed within 90 seconds.
- 5 Handset:**
Wait until “Enter Base PIN” is displayed. → Enter the base unit PIN (default: “0000”).
→ [/OK]
 - If you forget your PIN, contact an authorised service centre.
 - When the handset has been registered successfully,  stops flashing.








Deregistering a handset

- 1** [/OK]
- 2** []: “Base Unit Setup” → [/OK]
- 3** [][][] → [/OK]
 - All handsets registered to the base unit are displayed.
- 4** Enter the desired handset number you want to cancel. → [/OK]
- 5** []: “Yes” → [/OK]
 - A confirmation tone sounds.
 - The handset does not beep when cancelling its own registration.
- 6** []

Changing the base unit PIN (Personal Identification Number)

Important:

- If you change the PIN, please make note of your new PIN. The unit will not reveal the PIN to you. If you forget your PIN, contact an authorised service centre.

- 1** [/OK]
- 2** []: “Base Unit Setup” → [/OK]
- 3** []: “Base Unit PIN” → [/OK]
- 4** Enter the current 4-digit base unit PIN (default: “0000”).
- 5** Enter the new 4-digit base unit PIN. → [/OK] → []



Useful Information

Wall mounting



Note:

- Make sure that the wall and the fixing method are strong enough to support the weight of the unit.
- Drive the screws (not supplied) into the wall.

■ **Base unit**






■ **Charger**










Index

- A** Alarm: 20
Answering calls: 14
Auto talk: 14, 18
- B** Base unit
Resetting: 20
Battery: 9, 10
- C** Call share: 15
Call waiting: 15
Call Waiting Caller ID: 15
Caller ID service: 22
Caller list: 22
Caller list edit: 22
Character entry: 26
Conference calls: 25
- D** Date and time: 12
Dialling mode: 13
Display
Contrast: 18
Language: 12
- E** Eco mode: 13
Error messages: 28
- F** First ring: 19
- H** Handset
Deregistration: 31
Locator: 25
Registration: 31
Hold: 15
- I** Intercom: 25
- K** Keytones: 18
- M** Making calls: 14
Missed calls: 22
Mute: 15
- P** Pause: 14
Phonebook: 16
PIN: 31
Power failure: 10
Power on/off: 12
Privacy mode: 19
- R** Recall/flash: 15
Redialling: 14
Region settings: 12, 20
Repeater: 20
Ringer tone: 18
- S** Speakerphone: 14
- T** Temporary tone dialling: 15
Transferring calls: 25
- Troubleshooting: 28
- V** Voice mail: 24
Volume
Receiver: 14
Ringer (Handset): 14, 18
Speaker: 14
- W** Wall mounting: 32







Notes





Notes



C€0470

Sales Department:

■ Czech

Panasonic Marketing Europe
GmbH, organizační složka
Česká republika

Thámova 289/13 (Palác Karlin)
186 00 Praha 8

telefon: +420-236 032 511
centrální fax: +420-236 032 411
zákaznická linka: +420-236 032 911
e-mail: panasonic.praha@eu.panasonic.com
aktuální info na www.panasonic.cz

■ Slovakia

Panasonic Marketing Europe
GmbH, organizačná zložka
Slovenská republika

Štúrova 11, 811 01 Bratislava,
Slovenská republika

Telefón: +421-2-2062-2211
Fax: +421-2-2062-2311
zákaznická linka: +421-2-2062-2911
e-mail: panasonic.bratislava@eu.panasonic.com
aktuálne info na www.panasonic.sk

■ Romania

Panasonic Marketing Europe
GmbH, Wiesbaden, Germania,
Sucursala București, Romania

B-dul Preciziei, Nr. 24, West Gate Park,
Clădirea H3, Etaj 2, Sector 6,
București, 062204, Romania

Telefon: +40.21.316.31.61
Fax: +40.21.316.04.46
e-mail: suport.clienti@eu.panasonic.com
web: www.panasonic.ro

Panasonic System Networks Co., Ltd.

1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

© Panasonic System Networks Co., Ltd. 2012



PNQX5392ZA

PNQX5392ZA TT0912MU0 (A)

FX-2/3